

---


**RF01438**

TURNBUCKLE WITH FIXING SCREW




---

**WARNING!** When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.



Insert the end point of the steel cable into the upper hole of the turnbuckle and then fasten the locking screw.



Hook the turnbuckle to the counterweight (A).  
Regulate the turnbuckle in a way that the  
counterweight (A) almost touches the floor and then  
fasten the locking bolts.  
Verify that the suspension wire is perpendicular.

**WARNING!** Lifting up the counterweight will cause  
mechanical tension loss of the suspension wire,  
causing the tube and lamp support to fall down.