

EXTERNAL LAMP BODY



F1580057



F1580009




F1580026



F1580023

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.

For the installation of the spare-part, it is necessary to consult a qualified electrician.



Assemble the external body (L) onto the internal body (D) with the screws (M), ensuring to position the washers (N) in the correct positions (O).