

WIRERING RING ASSEMBLY



RF26676



RF26674



RF26675




RF26677




RF26678


WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.




Disconnect the body lamp from the old ring.



Remove the old ring from the wall.



Insert the new ring in the hole into the wall.



Connect the body lamp to the new ring respecting the correct installation direction.