

EXTERNAL DIFFUSER SET














WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.



Lock the external diffuser (A) to the inner diffuser (B) by forcing (pushing) it, until it clicks-on.