
SAWARU BASE



RF6640100



RF6640200




RF6640300



RF6640400

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.



Choose the device's working position from one of the three provided, then insert the pin (I) of the base (D) into the hole in the body chosen. Gripping the base with both hands as indicated in the figure so that the pin is properly centered with respect to the hole.

